


THE FUTURE OF FOUNDATION FORMWORK

THE PROFESSIONAL
WELDED MESH FORMWORK SYSTEM



TURNSTONE INDUSTRIAL SOLUTIONS, LLC.

www.turnstoneindustrial.com



A USER FRIENDLY SOLUTION

Standard Novoform™ is manufactured using 4mm main wires at 6 inch centers on 3mm cross wires at 3 inch centers. Designed, tested and proven to suit foundations containing reinforcement of depths up to 108 inches.

Our mesh is produced from cold drawn mild steel, manufactured to US Standards. The mesh is electronically welded at every intersection.

Our dedicated team will ensure that you are given precise, custom instructions regarding the details and assembly of Novoform $^{\text{\tiny TM}}$ on every order placed.





PANEL SIZES

All panels are 8 ft long, and are available in the following depths:

18 in	60 in
21 in	63 in
24 in	66 in
27 in	69 in
30 in	72 in
33 in	75 in
36 in	78 in
42 in	84 in
48 in	90 in
54 in	96 in
57 in	108 in






PILE CAP OR BASE ASSEMBLY - STEP BY STEP GUIDE

Cutting the Novoform™ pile cap panels allows easy access to fit reinforcement bars through the cap or base.



Pile cap area formed and leveled.

2 Using the Novoform™ instructions provided with order, identify the marked panels for cap and base and place against the spacers




All Novoform[™] panels marked per instuctions, for simple and rapid assembly.

Mark the panel outline on the side of the cap or base assembly, as drawn, ready to form opening connections




Use straight edge and marker to measure additional 1.0 inch width so panels fit inside 'doors'.

Cut center line and bottom line. Form 'inverted T', fold out 'doors', ready to accept Novoform™




Select preformed Novoform™ panels and place inside the open 'doors'. Attach joint with wire tire.



Leave top wire mesh intact and cut alternate wires at 'door' hinge line This helps to give a tight fold and makes the folding easier. The 'doors' act as the grout seal. Spacers may be removed at door openings.


TYPICAL SPACER ARRANGEMENT


Will vary by depth of cap/base and ground conditions. Spacer centers to be adjusted as required to maintain specified concrete cover. Spacers to be staggered, as shown, where practical.






NovoForm™ recommendation: Maximum Novoform™ spacer centers 18 inches.







TYPICAL "U" SECTION CONNECTIONS


Will vary by depth of cap/base and ground conditions. Spacer centers to be adjusted as required to maintain specified concrete cover. Spacers to be staggered, as shown, where practical.
















U SECTION INSTALLATION


Recommended construction sequence for reinforced concrete ground beams.




Excavate trench and form level base.




Position U section Novoform™ panel and place rebar chairs



Insert rebar cage with fixed Novoform™ plastic side spacers to line and level



Place loose backfill within top 2 inches of finished concrete level. Keep foot traffic and vehicles well clear of foundations under construction















NOVOFORM

THE FUTURE OF FOUNDATION FORMWORK

Novoform is an IBC and IRC certified product through Intertek.









Models of every project are developed by our expert team using the latest in CAD technology to ensure efficiencies of all projects and orders.

Learn more about our products and more

Visit www.turnstoneindustrial.com or email us at novoformsales@turnstoneindustrial.com



GLOBAL HEADQUARTERS

271 Gawthrop Drive, Winchester, KY 40391
Ph: (859) 745-8720

WEST VIRGINIA
25 Rodeo Drive, Fairmont, WV 26554
Ph: (304) 363-0868